

Ink-Jet cleaning swab usage (GS-00100-25)

The use of the Ink-Jet cleaning swab is intended as an “as needed” supplement to the documented cleaning procedures in the Operator Manual and the Panini Cleaning Kit. It is not meant to completely replace the cleaning procedure. The swabs are also only intended for use with the C6602a (CA-00138) single line ink-jet cartridges and **not** the AGP cartridges.

The swab is pre-moistened distilled water.

To use the swab

- First shutdown your capture application and unplug the machine.
- Remove the center cover from the Vision X and remove one swab from package.



- Slip the swab into the track as shown in Figure A (note that the swab is located at the top of the roller) and slide the swab from the front to the back (right to left) past the Ink Jet cartridge Figure B, note that the nozzles we want to clean are at the top of the cartridge.



Figure A



Figure B

- When swab is at the rear of the cartridge shown in Figure C lift up and out of the machine as shown in Figure D.



Figure C



Figure D

- Repeat this process a second time but first rotate the swab so the clean side is facing the cartridge.
- Replace the center cover.
- Plug in the machine.
- Restart your application.

This procedure will help with normal debris, dirt, and ink buildup on the MICR Read Head. For cartridges that have clogged nozzles causing missing lines in the print you might need to remove the cartridge and use the procedure specified in the Operator Manual.

To order this or other Panini cleaning products, please visit www.paniniportal.com.